

褂

MODBAR DESIGN GUIDE

CONTENTS


MB-00 COVER PAGE COVER PAGE SCHEMATIC DIAGRAM TYPICAL LAYOUT - ESPRESSO MODULE TYPICAL LAYOUT - STEAM MODULE MB-01 MB-02 MB-03 MB-04 TYPICAL LAYOUT - POUR OVER MODULE MB-05 TYPICAL SECTIONS TYPICAL MODBAR CONFIGURATION 1 TYPICAL MODBAR CONFIGURATION 2 MB-06 MB-07 MB-08 **TYPICAL MODBAR CONFIGURATION 3** MB-09 BENCH SETOUT - ESPRESSO MB-10 **BENCH SETOUT - STEAM** MB-11 **BENCH SETOUT - POUR OVER** MB-12 TYPICAL DETAILS

ANY ERRORS, DISCREPANCIES OR OMISSIONS IN THE DRAWINGS, NOTATIONS OR DIMENSIONS SHALL BE IMMEDIATELY BROUGHT TO THE ATTENTION OF MODBAR FOR CLARIFICATION PRIOR TO WORKS COMMENCING. DO NOT SCALE FROM DRAWINGS. USE MARKED DIMENSIONS. LOCATION OF ALL HARDWARE FIXTURES AND FITTINGS TO BE CONFIRMED ON SITE PRIOR TO WORKS COMMENCING. COPYRIGHT ON THIS DRAWING IS RETAINED TO MODBAR PTY LTD.

modbar



TITLE: DRAWING NUMBER: SCALE: ISSUE:



JOINERY (BY VENDOR)

MODBAR MODULE CLEARANCE ZONE

POWER FEED

WATER FEED

WASTE OUTLET

ESPRESSO, STEAM + HOT WATER OUTPUT

FINISHED FLOOR LEVEL


BENCH PENETRATION (BY VENDOR)

NOTE:

- 1. 'VENDOR' REFERS TO EQUIPMENT/SERVICES TO BE SUPPLIED PRIOR TO INSTALLATION OF MODBAR. DESIGNERS, CONTRACTORS, LANDLORDS AND OWNERS ARE TO COORDINATE THESE SERVICES DASHED LINES INDICATE EQUIPMENT
- 2. THAT MODBAR/INSTALLER WILL INCLUDE IN THE INSTALLATION
- 3. THE VENDOR IS RESPONSIBLE FOR PROVIDING ALL ITEMS IN SOLID OR OTHERWISE NOTED

NOTE: UNLESS NOTED OTHERWISE, ALL DIMENSIONS ARE IN MILLIMETERS. ANY ERRORS, DISCREPANCIES OR OMISSIONS IN THE DRAWINGS, NOTATIONS OR DIMENSIONS SHALL BE IMMEDIATELY BROUGHT TO THE ATTENTION OF MODBAR FOR CLARIFICATION PRIOR TO WORKS COMMENCING. DO NOT SCALE FROM DRAWINGS. USE MARKED DIMENSIONS. LOCATION OF ALL HARDWARE FIXTURES AND FITTINGS TO BE CONFIRMED ON SITE PRIOR TO WORKS COMMENCING. COPYRIGHT ON THIS DRAWING IS RETAINED TO MODBAR PTY LTD.

modbar



LEGEND

 JOINERY (BY VENDOR)

 MODBAR MODULE

 CLEARANCE ZONE

 POWER FEED

 WATER FEED

 WASTE OUTLET


 ESPRESSO, STEAM + HOT

 WATER OUTPUT

 FINISHED FLOOR LEVEL

 BENCH PENETRATION

 (BY VENDOR)



NOTE: UNLESS NOTED OTHERWISE, ALL DIMENSIONS ARE IN MILLIMETERS. ANY ERRORS, DISCREPANCIES OR OMISSIONS IN THE DRAWINGS, NOTATIONS OR DIMENSIONS SHALL BE IMMEDIATELY BROUGHT TO THE ATTENTION OF MODBAR FOR CLARIFICATION PRIOR TO WORKS COMMENCING, DO NOT SCALE FROM DRAWINGS. USE MARKED DIMENSIONS. LOCATION OF ALL HARDWARE FIXTURES AND FITTINGS TO BE CONFIRMED ON SITE PRIOR TO WORKS COMMENCING. COPYRIGHT ON THIS DRAWING IS RETAINED TO MODBAR PTY LTD.

modbar

LEGEND

 JOINERY (BY VENDOR)

 MODBAR MODULE

 CLEARANCE ZONE

 POWER FEED

 WATER FEED

 WASTE OUTLET


 ESPRESSO, STEAM + HOT

 WATER OUTPUT

 FINISHED FLOOR LEVEL

 BENCH PENETRATION

 (BY VENDOR)



NOTE: UNLESS NOTED OTHERWISE, ALL DIMENSIONS ARE IN MILLIMETERS. ANY ERRORS, DISCREPANCIES OR OMISSIONS IN THE DRAWINGS, NOTATIONS OR DIMENSIONS SHALL BE IMMEDIATELY BROUGHT TO THE ATTENTION OF MODBAR FOR CLARIFICATION PRIOR TO WORKS COMMENCING, DO NOT SCALE FROM DRAWINGS. USE MARKED DIMENSIONS. LOCATION OF ALL HARDWARE FIXTURES AND FITTINGS TO BE CONFIRMED ON SITE PRIOR TO WORKS COMMENCING. COPYRIGHT ON THIS DRAWING IS RETAINED TO MODBAR PTY LTD.

modbar

LEGEND

 JOINERY (BY VENDOR)

 MODBAR MODULE

 CLEARANCE ZONE

 POWER FEED

 WATER FEED

 WASTE OUTLET


 ESPRESSO, STEAM + HOT

 WATER OUTPUT

 FINISHED FLOOR LEVEL

 BENCH PENETRATION

 (BY VENDOR)





JOINERY (BY VENDOR)

MODBAR MODULE CLEARANCE ZONE

POWER FEED


WATER FEED

WASTE OUTLET

ESPRESSO, STEAM + HOT WATER OUTPUT

FINISHED FLOOR LEVEL

BENCH PENETRATION (BY VENDOR)



JOINERY (BY VENDOR)

MODBAR MODULE CLEARANCE ZONE

POWER FEED

WATER FEED


WASTE OUTLET


ESPRESSO, STEAM + HOT WATER OUTPUT

FINISHED FLOOR LEVEL


BENCH PENETRATION (BY VENDOR)

TYPICAL MODBAR CONFIGURATION 1 MB-06 1:10@A3 SEPTEMBER 2020






MODBAR MODULE CLEARANCE ZONE




NOTE:

LEGEND




BENCH PENETRATION (BY VENDOR)



PRIOR TO WORKS COMMENCING. COPYRIGHT ON THIS DRAWING IS RETAINED TO MODBAR PTY LTD.

LEGEND


JOINERY (BY VENDOR) MODBAR MODULE CLEARANCE ZONE POWER FEED WATER FEED WASTE OUTLET ESPRESSO, STEAM + HOT WATER OUTPUT FINISHED FLOOR LEVEL BENCH PENETRATION (BY VENDOR)



ATTENTION OF MOBBAR FOR CLARIFICATION PRIOR TO WORKS COMMENCING. DO NOT SCALE FROM DRAWINGS. USE MARKED DIMENSIONS. LOCATION OF ALL HARDWARE FIXTURES AND FITTINGS TO BE CONFIRMED ON SITE PRIOR TO WORKS COMMENCING. COPYRIGHT ON THIS DRAWING IS RETAINED TO MODBAR PTY LTD.

LEGEND


JOINERY (BY VENDOR) MODBAR MODULE CLEARANCE ZONE POWER FEED WATER FEED WASTE OUTLET ESPRESSO, STEAM + HOT WATER OUTPUT FINISHED FLOOR LEVEL BENCH PENETRATION (BY VENDOR)



PRIOR TO WORKS COMMENCING. COPYRIGHT ON THIS DRAWING IS RETAINED TO MODBAR PTY LTD.

LEGEND

JOINERY (BY VENDOR)
MODBAR MODULE CLEARANCE ZONE
 POWER FEED
 WATER FEED
 WASTE OUTLET
 ESPRESSO, STEAM + HOT WATER OUTPUT
FINISHED FLOOR LEVEL
BENCH PENETRATION (BY VENDOR)



NOTE:

modbar

LEGEND

JOINERY (BY VENDOR)

MODBAR MODULE CLEARANCE ZONE

POWER FEED

WATER FEED

WASTE OUTLET

ESPRESSO, STEAM + HOT WATER OUTPUT

FINISHED FLOOR LEVEL

BENCH PENETRATION (BY VENDOR)

NOTE:

- 1. 1 WASTE PIPE OUTLET PER MODBAR MODULE REQUIRED
- 2. VENDOR TO MAKE ALLOWANCE FOR ACCESS TO WASTE PIPE/TRAPS/PITS FOR REGULAR CLEANING AND MAINTENANCE
- VENDOR TO ALLOW SUFFICIENT WASTE 3. PIPE FALL TO ALL RELEVANT CODES/STANDARDS